



Welcome to the CLU-IN Internet Seminar

NARPM Presents...Vapor Intrusion Issues at the Hill Air Force Base
Sponsored by: EPA Office of Superfund Remediation and Technology
Innovation

Delivered: March 24, 2011, 2:00 PM - 4:00 PM, EDT (18:00-20:00 GMT)

Instructors:

Sandra Bourgeois, U.S. EPA Region 8 (bourgeois.sandra@epa.gov or (303) 312-6666)

Maple Barnard, U.S. EPA Region 8 (barnard.maple@epa.gov or (303) 312-6321)

Moderator:


Jean Balent, U.S. EPA, Technology Innovation and Field Services Division (balent.jean@epa.gov or (703) 603-9924)

Visit the Clean Up Information Network online at www.cluin.org

1

Housekeeping

- Please mute your phone lines, Do NOT put this call on hold
 - press *6 to mute #6 to unmute your lines at anytime
- Q&A
- Turn off any pop-up blockers
- Move through slides using # links on left or buttons



- This event is being recorded
- Archives accessed for free <http://clu.in.org/live/archive/>

2

Although I'm sure that some of you have these rules memorized from previous CLU-IN events, let's run through them quickly for our new participants.

Please mute your phone lines during the seminar to minimize disruption and background noise. If you do not have a mute button, press *6 to mute #6 to unmute your lines at anytime. Also, please do NOT put this call on hold as this may bring delightful, but unwanted background music over the lines and interrupt the seminar.

You should note that throughout the seminar, we will ask for your feedback. You do not need to wait for Q&A breaks to ask questions or provide comments. To submit comments/questions and report technical problems, please use the ? Icon at the top of your screen. You can move forward/backward in the slides by using the single arrow buttons (left moves back 1 slide, right moves advances 1 slide). The double arrowed buttons will take you to 1st and last slides respectively. You may also advance to any slide using the numbered links that appear on the left side of your screen. The button with a house icon will take you back to main seminar page which displays our agenda, speaker information, links to the slides and additional resources. Lastly, the button with a computer disc can be used to download and save today's presentation materials.

With that, please move to slide 3.

□

CASE STUDY VAPOR INTRUSION HILL AIR FORCE BASE, UT Other Federal Agency Lead



**Sandra Bourgeois, EPA R8
Annette Barnard, EPA R8**


March 24, 2011

3


□

OVERVIEW OF HILL AFB VAPOR INTRUSION PROGRAM


- **History**
- **Program Overview**
- **Mitigation**
- **Challenges and Optimization**
- **Community Involvement**
- **Exit Strategy**
- **Case Studies**
 - 1,2 DCA
 - Pressure Control Example
 - Preferential Flow



5




Adapted from Hill AFB, 2010




[illegible]

General investigation strategies



Charateristics of Vapor Intrusion at Hill AFB

- Hydrogeology
- VOC concentrations in groundwater
- Residential areas over and adjacent to groundwater plumes
- Military Installation... surrounded by houses
- Residential homes with and without basements ~ 50%




Vapor Intrusion Program

Approach

- Sample indoor air – Determine if exposure is occurring
 - 24-Hour samples analyzed to EPA Method TO 15
 - Project-dedicated, batch-certified clean Summa® canisters
 - Chemical inventory and inspection prior to sampling
- Advantages
 - Measure exposure concentration
 - Public relations
- Disadvantages
 - Doesn't distinguish vapor source

Air Sampling Focus Areas



13


Project Approach

- Indoor Air Sampling offered annually
 - Sample during cold months
 - Area-specific COC list
 - Only look for COCs in air that are present in nearby groundwater
 - 24-hr samples
- Established Action Levels
 - Agreed with EPA/State of UT

Compound	Mitigation Action Level	
	($\mu\text{g}/\text{m}^3$)	(ppbv)
Carbon Tetrachloride	1.6	0.26
1,1-Dichloroethane	15	3.8
1,2-Dichloroethane	0.94	0.23
1,1-Dichloroethene	209	53
cis-1,2-Dichloroethene	63	16
trans-1,2-Dichloroethene	63	16
Tetrachloroethene	4.1	0.61
Trichloroethene	12	2.3
Vinyl Chloride	2.8	1.1

CR= 1×10^{-5} or HI = 1

Simplified Decision Logic




15

Update

Hill Program Results

- Since January 2001:
 - 1820 of 2900 homes have agreed to sampling
 - >7500 samples collected
 - TCE detections in 290 (16%) of homes sampled
 - TCE detected above action level in 123 homes
 - 35 of these known or suspected indoor sources
 - 106 Sub Slab Depressurization (SSD) systems installed




16

Indoor Air 2010 Summary


- 2,710 letters sent
 - 633 agreed to sampling
 - 630 homes sampled
 - 77 homes had detection
 - 12 above action level (All interior sources*)
 - » 9 -Tetrachloroethene (PCE)
 - » 1 -Trichloroethene (TCE)
 - » 1 -Carbon Tetrachloride (CTCL)
 - » 1 -trans-Dichloroethene (tDCE)
 - Interior sources found in all above except one PCE home that did not agree to source investigation

MITIGATION





Mitigation

- Sub-slab depressurization systems
 - Have been effective when VI is source of vapors
 - Air Force pays for power/ maintenance and performance monitoring
 - Annual inspection
 - In many cases, will not be effective when an indoor source is present
 - But, we have seen cases where they do pull significant indoor air



19

Mitigation Efficiency



Typical Mitigation Costs


- **\$5,000 - \$10,000** **Simple SSD**
- **\$30,000** **Complex Case**

Advantages

Successful track rate


Application

Mitigation Results



22

Mitigation and indoor sources



- TCE detection frequency and concentration decrease post-mitigation
- In same homes, 1,2-DCA detection frequency and concentration increase post mitigation

23

Challenges and Optimization

- Interior sources
 - 1,2-DCA case study
 - Portable GC/MS
- Temporal variability

Community Involvement

- **Strong community outreach helps inform and prepare public**
- **Access issues**
- **Health & Safety Concerns**
- **Claims Process/Property Values**

Hill Program Review

- Summary
 - Apparent vapor intrusion into homes
 - VRS have been effective at reducing concentration below MALs
- Indoor sampling first approach
 - Overall positive reaction by residents
 - Reaction if we'd chosen another approach?
 - Indoor source problems
 - Potential over-estimate of VI impacts
 - Concern/frustration for residents

26

Decision Logic for New and Existing VRSs


- Minimize unnecessary VRSs
- Multiple-lines-of-evidence

Exit Strategy Recommendations

- Align areas with the risk of VI
- Install a comprehensive monitoring network and develop water-table concentration maps for each OU
- Use groundwater modeling and CSM to predict when the COC concentrations no longer pose a VI risk.


1,2-DCA Case Study

- No known products (indoor sources) with 1,2-DCA
- TCE & 1,2-DCA in groundwater
- Both 1,2-DCA and TCE on indoor COC list in entire area



1,2-DCA study (cont'd)

- Few detections early in program
- VR systems did not reduce concentrations
 - Suspected indoor source
 - Detections outside of 1,2 DCA plume



Doucette et al., 2010

Indoor source study

- Try to find a non-groundwater source




1,2-DCA study (cont'd)

- Initial indoor source study identified 1,2-DCA in a molded plastic decoration
 - Confirmed with laboratory emission rate testing (Doucette et al., 2010)
- Portable GC/MS – molded plastics are a significant source
 - Molded plastic decorations emitting 1,2-DCA have been identified in many (>20) homes.



1,2-DCA study

- Data review – other ‘lines of evidence’ VI is not the source
 - Detection frequency (over plume vs. not)
 - 1,2-DCA attenuation factors 10 to 100X those of TCE
 - Simplified modeling (J&E)



- EPA/UDEQ concurrence to remove 1,2-DCA from COC list


32

Portable GC/MS

- Instrumentation
- Approach
- Examples

Instrumentation

- Inficon HAPSITE® GC/MS
- Key features:
 - Custom Methods
 - (~6 min) sample turn time
 - “Clean” chromatograms
 - Target VOCs in SIM mode
 - “Positive” identification
 - Full scan using NIST library
 - Low quantitation limits
 - Chlorinated aliphatics in ppt



34

Investigation Approach

Follow the data...

- Area-by-area sampling
 - Basement, main level, garage
- Focused sampling in high concentration area
 - Room-by-room sampling
 - Container survey/sampling
 - Individual product survey, sampling, and emission rates




35

Confirming Interior Source

- Emission rate measurement
- Purpose: determine if consumer products are a primary source of target VOC

$$E = \frac{C}{V_t * t} \quad C_{air} = \frac{E}{IV}$$




Product	Emission Rate (µg/min)	Calculated Indoor ⁽¹⁾ (µg/m ³)	Risk Based Conc. ⁽²⁾ (µg/m ³)
Hobby adhesives (PCE)	12	3.0	0.41
Degreaser (TCE)	7	1.7	1.2
Toilet Cleaner (CT)	0.03	0.008	0.41

1. Box model assuming 2500 ft² home, 10 air exchanges/day
2. EPA Regional Screening Levels, May 2010 (10⁻⁶)

36

Interior Source Example


■ Area by Area Results (ppb_v)



37


Interior Source Example

- Room by Room Results - Upstairs (ppb_v)



38

Interior Source Example



39

Confirming VI

- Entry point sampling
 - Can be isolated
 - Best if done after interior source is ruled out
 - Best done in combination with building pressure control



40

Investigation Results

- HAPSITE
 - 45 Total investigations
 - 41 Homes = Interior sources
 - 2 Homes = VI related
 - 2 “ND” on day of investigation
- Total Homes with Interior Sources to date = 233
 - 63 unique products containing TCE
 - 95 unique products containing PCE
 - See Dettenmaier and Gorder, 2010 for details


41

Temporal Variability


- Two observed behaviors in homes likely to have VI
 - Steady Type – High detection frequency and low variability
 - High probability that one sample will:
 - » indicate if VI is occurring
 - » be good indicator of exposure concentration
 - Variable Type – Low detection frequency and high variability
 - Low probability that one sample sufficient to indicate occurrence of VI

42

Steady Type VI



Variable Type VI



44

Managing Temporal Variability


- Variable Type VI poses a number of problems
 - Access Expense/time of multiple samples
 - False positive/false negative results
 - Uncertainty for building occupants
- Sampling while controlling building pressure (P) is a way to manage temporal variability

Building Pressure Control

- Development for VI led by Tom McHugh (GSI) – See references
 - Induce positive or negative building P during investigation
 - To confirm VI, negative building P is most useful in turning VI on
 - Induced negative P provides a “worse than normal” case




VI & Pressure Control Example




47

Pressure Control Example



48


Conceptual Investigation Strategy



- Consider a single 'indicator' compound
 - Another way to avoid interior source
- Don't assume on-site analysis approach is more costly
 - One event vs. many
- Work with stakeholders to agree as much as possible before starting
- Be (or encourage) innovation!


Use average/max etc.
for comparison to
standard

Sewer VI Summary



50

Sewer VI Summary



Key Points

- Hill AFB chose to sample inside air for VI characterization
- VI is determined in some homes
- Indoor sources are very problematic
 - Some progress identifying sources
 - Looking toward more “top down” investigation
- Public reaction has been generally favorable
- Would choose indoor sampling approach again
 - Plan on ‘top-down’ characterization
 - Add better water-table characterization
 - Consider pre-screening for indoor sources

Acknowledgement: Jarrod Case, Hill AFB
Kyle Gorder, Hill AFB
Eric Dettenmaier, Hill AFB



54

References

- Doucette, W.J.; Hall, A.J.; Gorder, K.A. Emissions of 1,2-dichloroethane from holiday decorations as a source of indoor air contamination. *Ground Water Monitoring and Remediation* **2010**, 30 (1), 64-71.
- McHugh, T.; Gorder, K. Methods to distinguish between vapor intrusion and indoor sources of VOCs at residences near Hill AFB, Utah, USA. In *Vapor Emission to Outdoor Air and Enclosed Spaces for Human Health Risk Assessment: Site Characterization, Monitoring, and Modeling*; Saponaro, S., Sezenna, E., Bonomo, L., Eds.; Nova Science Publishers, Inc.: Hauppauge, NY 2010.
- Dettenmaier, E., and K.A. Gorder. Detailed Indoor Air Characterization and Interior Source Identification by Portable GC/MS. Presented to the Air and Waste Management Association Vapor Intrusion Specialty Conference, Chicago, IL. September 30, 2010.
http://events.awma.org/education/Presentations/Session%208/3_AF_AWMA_IA_09272010_EMD.pdf (accessed Feb 24, 2011)

Questions

Resources & Feedback

- To view a complete list of resources for this seminar, please visit the [Additional Resources](#)
- Please complete the [Feedback Form](#) to help ensure events like this are offered in the future

EPA United States Environmental Protection Agency
Technology Innovation Program

U.S. EPA Technical Support Project Engineering Forum
(Open Remediation Consulting the Door to Field Use Session C: Green Remediation Tools and Possibilities)
Seminar Feedback Form

We would like to receive any feedback you might have that would make this service more valuable.
Please take a few minutes to fill out this form before leaving this site.

First Name: _____
Last Name: _____
Email Address: _____
Date of Seminar: _____

☐ I would like to receive a copy of this newsletter and/or other information from EPA.

Need confirmation of
your participation today?
Fill out the feedback form
and check box for
confirmation email.