


HRSC Technologies and Methods for Mapping PFAS Concentrations and Mass Flux

Federal Remediation Round Table

November 7, 2023



Agenda

- Why does Flux matter?
- HRSC for PFAS RIs
- 4 Key Elements
- PFAS Considerations
- Buckley SFB Example
- Flux monitoring


Why Does Flux Matter?

Contaminant maps are only half of the story

- Flux distinguishes mass in high permeability and low permeability zones to better quantify mass transport

Mass Flux describes the concentration of contaminant movement

- Better understanding of risk
- Focus remedies to improve performance and cost efficiency



ESTCP-ER19-5203

Mass Flux and Mass Discharge

Mass Flux:

Mass flow across a unit area

$$J = K i C \text{ (mass/time/area)}$$

K = Hydraulic Conductivity

i = Hydraulic Gradient

C = Concentration


Mass Discharge:

Integrated mass flux


$$M_d = \int_A J \, dA \text{ (mass/time)}$$

J = Mass Flux


A = Total area



Adapted from ITRC, 2010




Doesn't high resolution mean high-cost characterization?



The return on investigation – life-cycle cost and performance optimization


Smart Characterization[®] : Find the Flux

Flux-Based CSM




- Majority of flux in permeable zones

Right tools to map flux




- Quantitative
- High-resolution

Real-time & adaptive



- Lower investigation costs


Interpretation



- 3D analysis
- Classical geologic approach

Stratigraphic Flux Framework for Transport

Evaluating mass flux based on the soil types and permeability structure of the aquifer



HRSC for PFAS?

Data Quality Objectives:

PFAS Compounds - Concentration

- Selectivity to accurately measure specific PFAS compounds
- Sensitivity to resolve specific compounds relative to USEPA risk-based screening levels
- Near real-time results to facilitate adaptive characterization


Stratigraphy and Hydraulic Conductivity (K)

- Continuous logging – essential to see facies trends
- Provide consistent and reliable estimates of K

Current PFAS Analytical Options

No field screening options


ASD memo requires USEPA Draft Method 1633



No PFAS Direct Sensing Technologies Exist

Compliant with QSM 5.4 Table B24

- Slow method/surging demand
- Significant Delays
- Up to 6 months for validated data
- High Costs, approx. \$375/sample



No PFAS Mobile Labs Available

Solution

Use workflow planning and HRSC sampling methods

- Vertical aquifer profile sampling, hand augers, passive flux meters, etc
- Screening methods with rapid turn-around

Current PFAS Analytical Options - Screening Levels Methods

Two Categories of Screening Level PFAS Techniques

Non-targeted screening methods – Examples are AOF by EPA 1621 and PIGE

- Total fluorine results, limited value
- RLs in ppb range – too high
- Not field deployable
- Relatively slow and expensive

RL too high and not selective

Targeted Screening Methods – ASTM D8421

- Target compound list – up to 40 compounds
- Easier method, rapid TAT = ~ 3 to 5 days
- Cost ~ \$250/sample
- Can meet most characterization DQO requirements

*Not real-time as with mobile labs
BUT...
Much faster and cheaper than using only 1633*

PFAS Analytical Screening Options

ASTM D8421 - Additional Information and Recommendations

- Rigorous multi-lab validation study using 11 environmental waters >>>
- DoD Acceptance: ASD Memo Dated 8/7/23 states “Other methods for analysis may be considered for screening samples to determine the presence or magnitude of PFAS concentration” Requires approval.
- Approval process - DMA with ARNG underway
- Used in conjunction with 1633 (USEPA Triad’s collaborative data collection)
- Capacity is strong – Pace, SGS, Elle and several other smaller labs providing this type of service.

Matrices Tested

- Landfill Leachate
- Metal Finisher
- POTW Effluent 1
- Hospital
- POTW Influent
- Bus Washing Station
- Powerplant
- Pulp and Paper
- POTW Effluent 2
- Ground Water
- Surface Water

Implementing Screening

- **Planning Phase**

- Define DQOs
 - Regulatory requirements
 - Interim data vs final data
 - Pace of work, phased vs. near real-time
 - Quantity and type of samples



Does adaptive/screening work make sense?

- Setup comparison studies
 - Split frequencies
 - Statistics – standard correlations and reliability evaluations
 - Evaluation of comparison data sets, look at reliability


- **Field Work Phase**

- Digital CSM to aid with data management and presentations
- Decision logic used for managing adaptive workflow

Geological Soil Description

Aquifers are Created by Complex Depositional Environments:

- Not homogenous
- Highly variable vertically and horizontally
- Features are directionally dependent
- Permeability will vary by several orders of magnitude within short distances




Characterizing aquifer variability key to flux-based CSM

Stratigraphic Logging

Interpret geology based on transport potential:

- Recommend Udden-Wentworth based soil descriptions
 - Principal and minor grainsize
 - Sorting
 - Density
 - Plasticity vs dilatency to distinguish silt from clay
- Graphical logs provide good first approximation to transport potential
- Reclassify existing logs using hydrofacies analysis



Sieve Analysis & K estimates

Grainsize and Sorting are the Primary Properties Determining Permeability

- Validate soil descriptions
- Use sieve analysis to verify soil descriptions and estimate hydraulic conductivity
- Best for evaluating coarser-grained sand and gravels
- Limitations with clay rich soils due to flocculation (<20%)

Standard ASTM Sieve Set	Udden-Wentworth Based Sieve Set
3"	1½"
2"	1"
1½"	¾"
1"	⅜"
¾"	#4
⅜"	#10
#4	#12
#10	#14
#20	#35
#40	#40
#60	#60
#100	#100
#140	#140
#200	#200
Hydrometer	#230
	Hydrometer

HydrogeoSieveXL: an Excel-based tool to estimate hydraulic conductivity from grain-size analysis


Direct Push Injection Logging Methods

For Shallow Systems (<100 ft bgs), Direct Push Drilling Methods can be used to Advance a Variety of Direct Sensing Equipment


- HPT – Hydraulic Profiling Tool
- APS - Waterloo Advanced Profiling System
- CPT – Cone Penetrometer Testing

Combination Drilling can Extend Depth of Direct Push Tools

- HPT or APS / Sonic
- Downhole Hammer




Sequence Stratigraphy and Hydrofacies Classification




Mass Flux Transects

- Sampling strategy on transects
 - Resolve variability in lithology and concentration distribution
 - Refine resolution to zoom in on hotspot or step-out for delineation
- Applied downgradient of source(s) or at installation boundary to support early decision making
 - Spatial trends between transects along flow can guide extrapolation to RBSLs for delineation during RI
 - Mass discharge provides measure of source strength for ranking and prioritization
 - Mass flux provides target for interim measures
- Sampling strategy on transects
 - Resolve variability in lithology and concentration




Transect F – PFOS Flux



Geology



Hydraulic Conductivity and Sample Concentration




Relative Mass Flux



Stratigraphic Flux – Buckley SFB




Looking East




Legend

Relative Mass Flux



Hydraulic Conductivity (ft/day)



Source Evaluation

Site-Specific Leaching Behavior


Understanding source strength is key to evaluate if PFAS in soil poses a risk to groundwater

Several methods:

- Ratio of soil concentration to groundwater concentration
- Synthetic Precipitation Leaching Procedure (SPLP)
- Lysimetry and pore water sampling

Estimate bulk partitioning through regression analyses

- Calculated mass loading at source compared to downgradient mass discharge = bulk attenuation factor
 - Empirical basis for site-specific soil-to-groundwater standard




Flux Monitoring

Property Boundary Transects

Property boundary transects – provide useful information and early warning of potential off-site migration



- Vertical aquifer profile (VAP) or monitoring wells are installed during initial phase of RI, when:
 - Plume suspected or confirmed at site perimeter
 - Groundwater flow and transport indicate potential for off-site migration
 - Off-site receptors are less than 1 mile from base perimeter
- Use perimeter results to rank and prioritize EECA/interim actions



Eielson AFB - Transect 2: PFOS in Groundwater


3D CSM - EIELSON AIR FORCE BASE ALASKA

Area for detailed flux-based monitoring
and injection of carbon for flux reduction



➤ DGI Scope (2024)

- Install 8 monitoring well clusters (24 wells)
- Low flow sampling at each well
- Slug testing at each well
- Deploy 9 passive flux meters (PFMs) per well (216 total)



500 ft wide transect targeting VAP04

- Compare and apply flux results to refine design of carbon injection program
- Monitor mass flux/discharge reduction following carbon injection

Q&A

Contact Us



Joseph Quinnan, PE, PG

Senior Vice President

North American Director –
Emerging Contaminants
Novi, Michigan

Joseph.Quinnan@arcadis.com

248-789-4951

References

Joseph Quinnan, Michael Rossi, Patrick Curry, Mark Lupo, Margaret Miller, Helmer Korb, Cameron Orth, Kristen Hasbrouck, 2021. Validation of streamlined mobile lab-based real-time PFAS analytical methods. ESTCP ER19-5203 final report. https://serdp-estcp-storage.s3.us-gov-west-1.amazonaws.com/s3fs-public/project_documents/ER19-5203_Final_Report.pdf

Joseph Quinnan, Michael Rossi, Patrick Curry, Mark Lupo, Margaret Miller, Helmer Korb, Cameron Orth, Kristen Hasbrouck, 2021. Application of PFAS-mobile lab to support adaptive characterization and flux-based conceptual site models at AFFF releases. Remediation Vol 31, No. 3, pp 7-26. <https://doi.org/10.1002/rem.21680>.

Patrick J. Curry, Nicklaus R.H. Welty, Alison J Yanites, Catharine Varley, and Joseph Quinnan, 2020. Stratigraphic flux- a method for determining preferential pathways for complex sites. Remediation Vol 30, No. 2. <https://doi.org/10.1002/rem.21644>

Joseph Quinnan, Patrick Curry, 2017. Stratigraphic Flux – A Method for determining preferential pathways for complex sites, Air Force Plant 4 – Chrome Pit 3, BAA 967. Air Force Civil Engineering Center.

Patrick Curry, Nicklaus Welty, Jess Wright, Dave Favero, Joseph Quinnan, 2016. Smart Characterization – An integrated Approach for Evaluating a Complex 1,4-Dioxane Site. Remediation Vol 27, No 1, pp-29-45. <https://doi.org/10.1002/rem.21495>

J.F. Devlin, 2015. HydrogeoSieveXL: an Excel-based tool to estimate hydraulic conductivity from grain-size analysis. Hydrogeology Journal. 23, pages 837–844.

Extra Slides

Site Investigation – Adaptive and Flux Based

Adaptive, flux-based investigations are scalable with *a la carte* components and include:

- Background sampling
- “Prescriptive / adaptive” source area delineation
- “Source strength” characterization
- Perimeter mass flux evaluation
- Storm-water and sediment sampling
- Groundwater-Surface Water Interface (GSI) evaluation
- Surface water and sediment sampling
- Flux-based groundwater monitoring

